




## VistaCurve Assembling Instruction

### Caution: preliminary notice


Assembling this screen and installing it requires some professional know how. You will need 2 persons, as the screen is too heavy and bulky to be handled by a single person. You will need to be able to evaluate a totally safe way to fix the provided brackets to the wall where it is to be installed, and to provide it. It can be rubber, steel or plastic wall plugs, or hollow wall anchors.

1° Place the protective sheet on a wide, clean surface sensibly larger than the complete screen. Place the 4 main extruded profiles on the protective sheet. The black velour side must be face down.

- If the screen is larger than 100", the length elements come in 2 parts. Assemble these elements with the connecting rods and 3 pins. Then, tighten the rods with the provided M6 screws.




2° Insert the 4 angle brackets in the provided channel of the vertical profiles extrusions.




PLEASE NOTE: Matching colour tags on the profile ends will make assembling much easier

Then adjust the 4 angles so as to slightly compress the angle foam gaskets



3° Tighten with the provided M6 screws





# VISTACURVE 70" to 190" COUPLING ELEMENT / WALL BRACKET STIFFENING HEAD



VISTACURVE 140" to 160" Radius: 17000 mm  
VISTACURVE 170" to 190" Radius: 19000 mm

**COUPLING  
ELEMENT  
2 PER SCREEN**

VISTACURVE 70" to 100" Radius: 13000 mm  
VISTACURVE 110" to 130" Radius: 15000 mm



**WALL BRACKET  
4 PER SCREEN  
( + 2 wall " Z " bracket )**

Company Info	
Name	<b>U-See Ltd.</b>
Address	Unit 17B Shephard Works Newham Street Birmingham B37 3YU
Tel / Fax	1 448 011 044 431 114




VISTACURVE 70" 80" 90" 96" 100"

Company Info.	
Name	LS-See Ltd.
Address	Unit 15, The Arcade, Barnham Lane, Chicks Dial 21P
Telephone	01494 666628

≤ 100"

ASSEMBLING INSTRUCTIONS

≤ 100"



1 SLIDE THE ANGLE BRACKETS INTO THE GROOVE OF EACH VERTICAL ELEMENT

2 INSERT 8 SCREWS (6x16 mm) USE THE HEX KEY (do not tighten)

3 SLIDE THE FIRST HORIZONTAL ELEMENT ONTO THE TOP ANGLE BRACKET

4 SLIDE THE SECOND HORIZONTAL ELEMENT ONTO THE BOTTOM ANGLE BRACKET

5 INSERT 4 SCREWS (6x16 mm) USE THE HEX KEY TIGHTEN

6 SLIDE SIMULTANEOUSLY THE 2 ANGLE BRACKETS OF THE SECOND VERTICAL ELEMENT INTO THE GROOVE OF EACH HORIZONTAL ELEMENT

7 INSERT 4 SCREWS (6x16 mm) USE THE HEX KEY TIGHTEN



### HOW TO INSERT THE FABRIC



It is safer to perceive the insertion position by simply inserting the tool once in the profile without the fabric. Then remove it, place the fabric over the profile and insert it inside.



Gripfix profile



Gripfix profile & inserted spatula





**Note:**

- Before inserting the fabric in the profile groove, apply a very slight tension. The progressive insertion into the groove will significantly increase this tension.
- To insert the tool in the profile, start from the small straight edge, then gently push the fabric inside the by a rotation movement along the curved edge. Once you have reached the end of the curved edge, take the tool out of the profile and start again.
- During the whole process of fixing the Enlightor fabric and the Black Backing, the stiffening bars should remain inserted (to respect a constant height). They are just moved sideways by sliding
- Check that the tension is sufficiently uniform to avoid uneven bending of the screen frame. It must be only sufficient to avoid any wave or wrinkle.
- Once the white fabric is stretched, check the evenness of the surface. The tension is not to be excessive. In case of a problem, release locally the fabric from the profile, and insert it again.
- Insert the Black Backing fabric the same way in the same groove as the Enlightor fabric. Stretch it evenly.
- Fix the complete assembly onto a wall by inserting the pi-grips of the 4 wall brackets into the corresponding grooves.

**Note:** the adhesive logo is provided separately. Please stick it at the centre bottom of the lower horizontal element.



## HOW TO FIX THE SCREEN TO A WALL

1 x pair of “ Z ” brackets for hanging the top of the screen onto the wall



- 4 brackets to hold the upper and lower part of the screen (already fixed on the 2 coupling elements).



Fix 2 wall brackets “ Z “ onto the wall.

- Draw a horizontal line (use a spirit level) on the wall at the height that you have defined (see the drawings) to fix the two top “ Z “ brackets.
- Hang the screen
- Draw precisely a mark for each hole of bottom brackets
- Unhook the frame
- Fix two screws to the wall
- Hang the screen again
- To secure tighten the two bottom screws

SUPPLIED WALL BRACKETS ( 2 Pieces : Z )



